

keeping it safe

simple steps to site security





1 Trailer locks and tow hitch locks prevent removal.



2 When leaving equipment overnight on sites, secure compressors under boom arms of mini excavators. Use immobilisers or hydraulic locks to prevent removal.

If leaving mini excavators remove from trailer, slew cab and extend boom arms. Use immobilisers and/or hydraulic locks. This makes the machine impossible to remove or lift away. Note the use of CESAR registration and corporate livery. Criminals dislike stealing this type of equipment due to expense of repainting equipment.

3



4 Secure equipment together to prevent it either being lifted or dragged away. Use immobilisers and/or hydraulic locks with chain and padlocks.



5 For attachments and buckets, weld plant numbers and company logos/details to aid identification.

6

Secure trailers and equipment to each other or to road furniture. Lift all chains from ground to prevent easy attacks and space for cutters/bolt croppers to be used. Invest in good quality approved chains and padlocks.



7

Make the thief's life harder. Equipment removed from trailer and boom arms extended and immobilisers and/or hydraulic locks set preventing easy removal.



8

Boom arms and legs extended and immobilisers and/or hydraulic locks set. This telehandler now becomes nearly impossible to remove quickly by thieves.

10 simple steps

things to avoid



9

Take your keys with you. You wouldn't leave your keys in your car or transit van, but this is an all-too familiar sight.



10

Leaving your machine on a trailer, unlocked with no hitch lock. This machine can be stolen in seconds.

For added security consider installing the CESAR system as you are **four times** less likely to become a victim of crime.

For details follow any of the links below.

www.datatag.co.uk

www.cesarscheme.org

www.thamesvalley.police.uk/ruralcrime

